


# Technical Information Pyramid RF



A compatible reader (for example: Breeder Reader RF) can be connected wireless to the Pyramid RF.

The Pyramid RF is connected to the PC using USB, the software PlanetRouting is included.



## Flow of data

